

CRUISE CONTROL

OR AUXILIARY HEATER

AUXILIARY HEATER  
CRUISE CONTROL




→ CRUISE CONTROL

→ CRUISE CONTROL →

→ A/C →

→ AUXILIARY HEATER →

CRUISE CONTROL  
MODULE  
(PAGE 131)



RPO CODES

- C36 - AUXILIARY HEATER
- C60 - AIR CONDITIONING
- K34 - CRUISE CONTROL
- LB4 - ENGINE, 4.3L (262 CID) V8 GAS ENGINE, VN Z
- LH6 - ENGINE, 6.2L (376 CID) V8 DIESEL ENGINE, VN C
- LL4 - ENGINE, 6.2L (376 CID) V8 HD DIESEL ENGINE, VN J
- LO3 - ENGINE, 5.0L (305 CID) V8 GAS ENGINE, VN H
- LO5 - ENGINE, 5.7L (350 CID) V8 GAS ENGINE, VN K
- L19 - ENGINE, 7.4L (454 CID) V8 GAS ENGINE, VN N

