

- 1- NUT, HEXAGON JAM (M14x1.5)
- 2- GUARD ASM, LOCK BOLT
- 3- RING, RETAINING
- 4- LOCK, SHAFT
- 5- CAM, TURN SIG CANCEL
- 6- SPRING, UPPER BEARING
- 7- SCREW, BNDG HD CR RECESS
- 8- SCREW, RD WASH HD (M4.2X1.41)
- 9- ARM, SIGNAL SWITCH
- 10- SWITCH ASM, TURN SIGNAL
- 11- KNOB, HAZARD WARN SWITCH
- 12- SPRING, HAZARD WARNING
- 13- BUTTON, HAZARD WARNING
- 14- SCREW, OVAL HD C/REC (M3.5X1.27)
- 15- SEAT, UPPER BRG INNER RACE
- 16- RACE, INNER
- 17- SCREW, PAN HD SOC TAP
- 18- SWITCH ASM, BUZZER
- 19- SCREW, LOCK RETAINING
- 20- COVER ASM, BRACKET &
- 21- SCREW, RD WASH HD (M4.2X1.41X14)
- 22- HOUSING ASM, TRANS IND DIAL &
- 25- LOCK CYLINDER SET, STRG COL
- 26- RING, COVER TRIM
- 27- PIN, SWITCH ACTUATOR PIVOT
- 28- SWITCH ASM, PIVOT & (PULSE)
- 29- BASE PLATE, COL HSG CVR END
- 30- CAP, COL HSG COVER END
- 31- PROTECTOR, WIRING
- 32- ACTUATOR, DIMMER SW ROD
- 33- COVER LINER ASM, PIN &
- 34- HOUSING ASM, STRG COLUMN
- 35- BEARING ASM
- 36- SHOE, STEERING WHEEL LOCK
- 37- SHOE, STEERING WHEEL LOCK
- 38- SHIELD, WIRE PROTECTOR
- 39- PIN, DOWEL
- 40- PIN, PIVOT
- 41- SPRING, SHOE
- 42- SPRING, RELEASE LEVER
- 43- PIN, RELEASE LEVER
- 44- LEVER, SHOE RELEASE
- 45- RACK ASM, SWITCH ACTUATOR
- 46- SPRING, RACK PRELOAD
- 47- HOUSING, STRG COLUMN
- 50- GUIDE, SPRING
- 51- SPRING, WHEEL TILT
- 52- RETAINER, SPRING
- 55- SHAFT ASM, STEERING
- 56- SHAFT ASM, RACE & UPPER
- 57- SPHERE, CENTERING
- 58- SPRING, JOINT PRELOAD
- 59- SHAFT ASM, LOWER STEERING
- 61- SCREW, SUPPORT
- 62- SUPPORT ASM, STRG COL HSG

- 63- SUPPORT, STRG COL HSG
- 64- SCREW, OVAL HD CROSS RECESS
- 65- GATE, SHIFT LEVER
- 66- RING, SHIFT TUBE RETAINING
- 67- WASHER, THRUST
- 68- PLATE, LOCK
- 69- WASHER, WAVE
- 70- SPRING, SHIFT LEVER
- 71- POINTER, TRANS CONT INDICATOR
- 72- CLIP, POINTER RETAINING
- 73- BRACKET, POINTER RETAINING
- 74- BOWL ASM, GEARSHIFT LEVER
- 75- SHROUD, GEARSHIFT BOWL
- 76- TUBE ASM, SHIFT
- 77- SCREW, LEVER SUPPORT MTG
- 78- PLATE, DEFLECTOR
- 79- JACKET ASM, STRG COL
- 80- RETAINER, CAM
- 81- CAM ASM, CABLE SHIFT
- 82- SWITCH ASM, IGNITION
- 83- BRACKET, CONNECTOR BODY
- 84- SCREW, PAN HD SOC
- 85- ROD, DIMMER SWITCH
- 86- NUT, HEX (#10-24)
- 88- SWITCH ASM, DIMMER
- 89- STUD, DIMR SW MOUNTING
- 90- BRACKET ASM, STUD &
- 91- SOLENOID ASM, INTERLOCK
- 92- SCREW, HEX WASHER HEAD
- 93- ACTUATOR ASM, CABLE &
- 94- BRACKET ASM, SOLENOID
- 95- CLIP, STRG SHAFT COLLAPSE
- 96- SEAT, INNER RACE
- 97- BEARING ASM, ADAPTER &
- 98- BRACKET ASM, LOWER COL SUP
- 99- SCREW, PAN HD C/REC (M6X1)
- 100- SCREW, HEX WASH HD TAP
- 101- SEAT, LOWER BEARING
- 102- SPRING, LOWER BEARING
- 103- RETAINER, LOWER SPRING
- 104- RETAINER, BEARING & SEAL

Service Kits

- 201- SPRING SERV KIT, TILT COLUMN
-INCLUDES: 15,16,40,50,51,52
- 202- SPHERE SERV KIT, TILT COLUMN
-INCLUDES: 57,58
- 203- GREASE SERV KIT, (SYNTHETIC)
- 204- GREASE SERV KIT, BTSI

